

<Step 1: Peeling Off >
1. Peel off Deck from Transferring film
2. Use Water spraying on both Adhesive sides of Wooden deck and kit deck for easy locating.

<Step 2 : Remove the additional holes>
1. Remove the light blue area after locating and applying of Deck 1. Before attaching, paint the PE parts with Deck Blue

<Step 4 : Masking Sheet>
1. DarkBlue is Flight Deck Line.
2. SkyBlue is guide hole for location.
So after locating, please mask these holes too.

<Step 5 : Dry Transfer>
1. Please refer your own references for the Station numbers from -10Ft to 790Ft

